FOLLOWING OPTIONS: 1. WELD EACH TAB USING MINIMUM 1" WELD ALONG TAB END 2. USE (2) HILTI X-U 12 POWDER DRIVEN PINS THROUGH EACH TAB 3. USE (2) #14 TEKS 5 SELF-DRILLING SCREWS ÆACH TAB WHERE REQUIRED: MINIMUM 54 MIL WEB STIFFENER. ATTACH TO WEB OF JOIST USING (6) SCREWS. JOIST HANGERS: SIZED TO MATCH DEPTH AND FLANGE WIDTH OF EACH JOIST. ATTACH TO WEB OF EACH JOIST USING MINIMUM (1) DOUBLE OR SINGLE JOIST MEMBER. SEE PLAN FOR SIZE AND CONFIGURATION.

ALL SCREWS ARE #12 UNLESS NOTED OTHERWISE TOUCH UP ALL WELDS WITH ZINC-RICH PAINT.

ATTACH TOP TABS OF JOIST HANGER TO STRUCTURAL BEAM USING ONE OF THE

JOIST HANGER ON WF BEAM

